

<p>69</p> <p>NWN AI</p> <p>R4.00mm (.158") Tan 15°-94° 15° - 5.52mm (.217")</p> <p>WA1-NWN5121</p>	<p>70</p> <p>NWN AI</p> <p>R5.00mm (.197") Tan 15°-94° 15° - 5.00mm (.197")</p> <p>WA1-NWN5428</p>	<p>71</p> <p>NWN AI</p> <p>R2.00mm (.079") Tan 75°-94° R6.50mm (.256") Tan 15°-75° 15° - 3.00mm (.118")</p> <p>WA1-NWN2002</p>
<p>72</p> <p>NWN AI</p> <p>R7.00mm (.276") Tan 15°-94° 15° - 4.19mm (.165")</p> <p>WA1-NWN5429</p>	<p>73</p> <p>NWN B3</p> <p>R7.00mm (.276") Tan 15°-94° 15° - 6.42mm (.253")</p> <p>WB1-NWN077</p>	<p>74</p> <p>NWN AI</p> <p>R2.00mm (.079") Tan 20°-94° 20° - 4.00mm (.157")</p> <p>WA1-NWN2003</p>
<p>75</p> <p>NWN AI</p> <p>R12.00mm (.472") Tan 45°-94° 20° - 3.00mm (.118")</p> <p>WA1-NWN2004</p>	<p>76</p> <p>NWN AI</p> <p>R4.00mm (.157") Tan 30°-94° 30° - 6.00mm (.236")</p> <p>WA1-NWN5168</p>	<p>77</p> <p>NWN AI</p> <p>R5.00mm (.197") Tan 30°-94° 30° - 5.50mm (.216")</p> <p>WA1-NWN5079</p>

<p style="text-align: right;">78</p> <p>NWN AI</p> <p>R7.00mm (.276") Tan 30°-94° 30° - 4.00mm (.157")</p> <p style="text-align: center;">WA1-NWN5430</p>	<p style="text-align: right;">79</p> <p>NWN AI</p> <p>R5.00mm (.197") Tan 32°-94° 32° - 5.00mm (.197")</p> <p style="text-align: center;">WA1-NWN2005</p>	<p style="text-align: right;">80</p> <p>NWN B3</p> <p>R22.00mm (.866") Tan 45°-88°</p> <p style="text-align: center;">WB3-NWN690</p>
<p style="text-align: right;">□</p> <p style="text-align: center;">WA1-NWN5430</p>	<p style="text-align: right;">□</p> <p style="text-align: center;">WA1-NWN2005</p>	<p style="text-align: right;">□</p> <p style="text-align: center;">WB3-NWN690</p>
<p style="text-align: right;">□</p>	<p style="text-align: right;">□</p>	<p style="text-align: right;">□</p> <div style="text-align: right;"> </div>

<p>81</p> <p>NWN AI</p> <p>45° - 3.00mm (.118") R1.00mm (.039") Tan 0°-45°</p> <p>WA1-NWN2007</p>	<p>82</p> <p>NWN B3</p> <p>75° - 10.69mm (.421") R7.00mm (.276") Tan 0°-75°</p> <p>WB3-NWN002</p>	<p>83</p> <p>NWN AI</p> <p>75° - 5.50mm (.216") R12.00mm (.472") Tan 55°-75°</p> <p>WA1-NWN2008</p>
<p>84</p> <p>NWN AI</p> <p>75° - 5.50mm (.217") R12.00mm (.472") Tan 60°-75°</p> <p>WA1-NWN2009</p>	<p>85</p> <p>NWN AI</p> <p>80° - 5.50mm (.216") R3.00mm (.118") Tan 0°-80°</p> <p>WA1-NWN2010</p>	<p>86</p> <p>NWN B3</p> <p>80° - 9.81mm (.386") R7.00mm (.276") Tan 0°-80°</p> <p>WB3-NWN033</p>
<p>87</p> <p>NWN AI</p> <p>R4.50mm (.177") Tan 0°-94°</p> <p>WA1-NWN21045</p>	<p>88</p> <p>NWN AI</p> <p>R5.00mm (.197") Tan 0°-94°</p> <p>WA1-NWN21050</p>	<p>89</p> <p>NWN AI</p> <p>R6.00mm (.236") Tan 0°-94°</p> <p>WA1-NWN2011</p>